

CANDLE REFILL KIT - developed for Himalayan wooden candles. NOT recommended for Himalayan glass vessels. See other side for sizes. This kit comes with 4 oz scented (or unscented) soy wax cubes, cotton wicks, dye chips and glue dots to glue down the wicks.

STEP 1

It's best to start with a clean container - scrape off wax remnants and the burnt out wicks with a butter knife. Best results can be had by putting the wood container in the freezer before hand but this is not essential. Wooden trays must use the metal strip that the wicks are attached to.


STEP 2

Glue the wicks - evenly spacing them out using the glue dots. Use the same number of wicks as the original candle.

STEP 3

Melt the wax cubes. We recommend using a pyrex measuring jug on low heat on an electric stove or a microwave, or a heavy bottomed pot on a gas stove. If you are using a microwave, heat for 60 seconds at a time to avoid over heating. 60 seconds is enough to melt 4 ozs of wax, or one cube. If desired you can add dye chips to the melted wax to give a golden caramel tint to the wax. Clean up with hot water and detergent (not the dishwasher).

STEP 4

Pour the melted wax into the prepped wooden container. Let sit for at least 24 hours before use. Trim wicks to 1/2 inch. **LIGHT  ENJOY**

